

OPERATING MANUAL

READ ALL INSTRUCTIONS
BEFORE USING

MODEL DK-10302
SLIMMING MASSAGE BELT



FUNCTIONS

1. Multi-Functions, strong revolving vibration
2. 3 modes, 5 levels speed adjustable
3. Forward/Reverse function can reduce fat properly
4. Widely used for arm, thigh, calf, abdomen, waist etc
5. Time preset function, easy to use
6. Wide input switching voltage
7. Timer: 10 minutes


OPERATION

1. Tie up the slimming massage belt on the proper position for body, such as waist, abdomen etc. Tension and adjust to comfortable.
2. Connect the controller to body slimming massage belt first, then connect to the adaptor, finally insert the adaptor plug to the power socket.
3. **POWER** Button: Initiate or switch off the massager. Press once **POWER** button, working in manual mode, intensity is level 3. Press again to turn off the belt.
4. **AUTO** Button: Switch working mode to manual or auto. Press once **AUTO** button, working in auto mode, intensity increase from level 1 to level 5, then reduce from level 5 to level 1. Press again to switch to manual mode, the timer restarts.

5. **REVERSE** Button: Press **REVERSE** button to switch forward/reverse vibration.
6. **HI** Button: Press once **HI** button to increase intensity level, total 5 levels. This button is workable when the belt working in manual mode.
7. **LO** Button: Press once **LO** button to reduce intensity level. This button is workable when the belt working in manual mode.

If you feel itching when using the belt, it is not the side-effect, it is the reaction of the body, you can continue using it. We suggest using the belt no more than 30 minutes each time, no more than 10 minutes for same part of the body.

CONTROLLER & PARTS



Adapter



Handbag



Extension Belt

Item: Slimming Belt
Voltage: AC 100V-240V
50/60Hz
DC 24V 2A
Power: 48W