

OPERATING MANUAL

READ ALL INSTRUCTIONS
BEFORE USING

MODEL DK-108B



FUNCTION

1. 7 powerful DC motors
2. 9 modes massage; 3 levels strength
3. Relieving your neck, back, lumbar and thighs
4. Microcomputer control; 10, 20, 30 minutes timer
5. Used in car, office and home

GETTING STARTED

1. Pull the two straps around seat back.
2. Connect either the AC or DC adapter to the cushion and outlet.
3. Position yourself comfortably on the cushion and use the hand controller to select all functions.

CONTROLLER INSTRUCTIONS



Power: Press to turn on / off the massage cushion.

Mode: Press to choose different mode, total 9 modes. 9 modes change in circulation.

Orientation: Press to choose the massage position only on Back/ Lumbar/ Thighs. The corresponding LED light.

AutoMatic: The massage cushion works in automatic mode by pressing this button.

Timer: 3 modes, 10 minutes / 20 minutes / 30 minutes.

Head: Press to turn on / off neck massage.

Intensity: Press to choose the 3 different strength mode.

CAUTION

- I If you have any concerns regarding your health, consult your doctor before using this product.
- I If you experience pain in a muscle or joint for a prolonged period of time, discontinue use and consult your doctor. Persistent pain could be a symptom of a more serious condition.
- I Do not use the massage motors or heat for longer than 30 minutes. Extensive use could lead the product to becoming excessively hot. Should this occur, discontinue use and allow the unit to cool before operating.
- I Use only the adapter supplied with this product.
- I Disconnect from power source before cleaning.
- I Do not place in any liquid to clean. Clean fabric cover by wiping with a damp sponge, using a mild detergent or suds. Pat dry with clean, dry cloth.
- I Do not use abrasive cleaners, brushes, gasoline, kerosene, glass/furniture polish, paint thinner or water hotter than 120 F to clean the unit.
- I Place unit in its box or safe, dry, cool place. Avoid contact with sharp edges or pointed objects, which might cut or puncture the fabric. Do not wrap power cord around the unit. Do not hang the unit by the power cord.